



DESCRIÇÃO TEXTUAL DA SAÍDA

SAÍDA TEDAT 1:

Após decolagem, subir para 1000' (VA) no rumo 004, curvar à direita (DF) para o waypoint fly-by TEDAT. Então...

I - TRNS AMBET:

Curvar à esquerda (TF) rumo 074, voar 23.0 NM para a interseção fly-by AMBET.

II - TRNS ISADO:

Curvar à esquerda (TF) rumo 045, voar 36.8 NM para interseção fly-by ISADO.

SAÍDA ANDOX 1B:

Após decolagem, manter (CF) rumo 004, passar waypoint fly-by ANDOX a ou abaixo do FL060. Então...

I - TRNS JPS:

Curvar à direita (TF) rumo 027, voar 43.0 NM para NDB fly-by JPS.

II - TRNS SAFUC:

Curvar à direita (TF) rumo 017, voar 57.4 NM para interseção fly-by SAFUC.

DEPARTURE TEXTUAL DESCRIPTION

TEDAT 1 DEPARTURE:

After take off, climb to 1000' (VA) on track 004, turn right (DF) to TEDAT waypoint fly-by. Then...

I - AMBET TRNS:

Turn left (TF) track 074, fly 23.0 NM to AMBET intersection fly-by.

II - ISADO TRNS:

Turn left (TF) track 045, fly 36.8 NM to ISADO intersection fly-by.

ANDOX 1B DEPARTURE:

After take off, maintain (CF) on track 004, pass ANDOX waypoint fly-by at or below FL060. Then...

I - JPS TRNS:

Turn right (TF) track 027, fly 43.0 NM to JPS NDB fly-by.

II - SAFUC 1B DEPARTURE:

Turn right (TF) track 017, fly 57.4 NM to SAFUC intersection fly-by.