



CHANGES: EAC, FREQ, RMK.

DESCRIÇÃO TEXTUAL DA SAÍDA

I - SAÍDA TOSOM 1: Após decolagem, manter rumo 184 até 1000'. Curvar à esquerda, direto TOSOM. Então...

TRNS AMBET:

Curvar à direita (TF) rumo 065, voar 24.9 NM para interseção fly-by AMBET.

TRNS ISADO:

Curvar à direita (TF) rumo 041, voar 39.8 NM para interseção fly-by ISADO.

II - SAÍDA ANDOX 1A: Após decolagem, manter rumo 184 até 1000'. Curvar à esquerda, direto para RF009 acima do FL070. Curvar à esquerda rumo 319 até ANDOX. Então...

TRNS JPS:

Curvar à direita (TF) rumo 027, voar 43.0 NM para NDB fly-by JOÃO PESSOA.

TRNS SAFUC:

Curvar à direita (TF) rumo 017, voar 57.4 NM para interseção fly-by SAFUC.

DEPARTURE TEXTUAL DESCRIPTION

I - TOSOM 1 DEPARTURE: After take off, maintain course 184 until 1000' (VA), turn left (DF) to TOSOM. Then...

AMBET TRNS:

Turn right (TF) track 065, fly 24.9 NM to AMBET intersection fly-by.

ISADO TRNS:

Turn right (TF) track 041, fly 39.8 NM to ISADO intersection fly-by.

II - ANDOX 1A DEPARTURE: After take off, maintain course 184 until 1000' (VA), turn left (DF) to RF009 at or above FL070, turn left (TF) track 319 until ANDOX. Then...

JPS TRNS:

Turn right (TF) track 027, fly 43.0 NM to JOÃO PESSOA NDB fly-by.

SAFUC TRNS:

Turn right (TF) track 017, fly 57.4 NM to SAFUC intersection fly-by.