

Identification	Aerodrome	Chart Code	AIRAC AMDT
RNAV ARVIB 1B - VURLA 1B - GEDIR 1B - PUNVA 1A - KOVTI 1B RWY 25	IMPERATRIZ / Prefeito Renato Moreira (SBIZ)	SBIZ_SID_00L	28 JAN 21

Seq	Transition	Path Terminator	Navaid / Fix / WPT	Type / Function	Flyover (Y/N)	Navaid	Course Mag (True)	Dist (NM)	Turn (L/R)	IAS (KT)	Altitude (FT)	Gradient (%)	Perform.	
DEPAR	DEPARTURE RNAV ARVIB 1B													
010	Enroute	VA					255 (234.0)				+2500		RNP-1	
020	Enroute	DF	ILVAV		Y				R				RNP-1	
030	Enroute	TF	ARVIB		Ν		022 (001.0)	28.1	R				RNP-1	
DEPARTURE RNAV VURLA 1B														
010	Enroute	VA					255 (234.0)				+2500		RNP-1	
020	Enroute	DF	VURLA		Y				R				RNP-1	
DEPARTURE RNAV GEDIR 1B														
010	Enroute	VA					255 (234.0)				+2500		RNP-1	
020	Enroute	DF	GEDIR		Y				L				RNP-1	
DEPARTURE RNAV PUNVA 1A														
010	Common	VA					255 (234.0)				+2500		RNP-1	
020	Common	DF	PUNVA		Y				L				RNP-1	
RICAR TRANSITION														
010	Enroute	IF	PUNVA											
020	Enroute	TF	RICAR		Ν		172 (150.5)	51.0	L				RNP-1	
CNA	TRANSITION		-					-			-			
010	Enroute	IF	PUNVA											

020	Enroute	TF	CNA		Ν		195 (174.1)	80.5	R			 RNP-1	
INTEL TRANSITION													
010	Enroute	IF	PUNVA									 	
020	Enroute	TF	INTEL		N		199 (177.7)	75.4	R			 RNP-1	
DEPARTURE RNAV KOVTI 1A													
010	Enroute	VA					255 (234.0)				+2500	 RNP-1	
020	Enroute	DF	ΚΟΥΤΙ		Y				R			 RNP-1	

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
GEDIR	S 05:56:13.20W 46:32:51.00
KOVTI	S 05:31:39.60W 48:25:23.40
CNA	S 07:19:07.20W 47:27:17.40
PUNVA	S 05:58:41.86W 47:35:33.07
RICAR	S 06:43:20.40W 47:10:18.60
INTEL	S 07:14:21.00W 47:32:31.80
VURLA	S 05:01:25.55W 46:53:35.90
ILVAV	S 04:53:49.23W 47:43:43.75
ARVIB	S 04:25:36.00W 47:43:15.00

DER	Latitude / Longitude (WGS84) DD:MM:SS.SS	Elevation (FT)	COD
25	S 05:32:09.85 W 47:27:59.60	419.00 ft MSL	+
			-
			=
			SDF
			Y
			Ν
			L
			R

Meaning AT OR ABOVE AT OR BELOW MANDATORY

RECOMMENDED

STEPDOWN FIX YES NO LEFT RIGHT