



CODING TABLE

IAC VOR V RWY 30					ARACAJU / Santa Maria, INTL (SBAR)							SBAR_IAC_00E		16 JUL 20	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST	VA (°)	Role of the Fix	Navigation Specification
10	APCH	N/A	ARU	ARU	IF	N/A	N/A	N/A	+3000	N/A	N/A	N/A	N/A	IAF	N/A
20	APCH	N/A	ARU	ARU	FC	137.21° Mag	N/A	N/A	+2000	N/A	N/A	12 NM	N/A	N/A	N/A
30	APCH	N/A	ARU	SIKAT	CF	295.93° Mag	L	N/A	+2000	N/A	N/A	N/A	N/A	IF	N/A
10	FINAL	N/A	N/A	SIKAT	IF	N/A	N/A	N/A	+2000	N/A	N/A	N/A	N/A	IF	N/A
20	FINAL	N/A	ARU	PAKAD	CF	295.98° Mag	N/A	N/A	R1350	N/A	N/A	5.00	N/A	FAF	N/A
30	FINAL	N/A	ARU	ARU03*	CF	296.00° Mag	N/A	N/A	@72	N/A	N/A	4.00	-3.02	MAPT	N/A
10	MA	N/A	ARU	N/A	CA	296.00° Mag	N/A	N/A	+2000	N/A	N/A	N/A	N/A	N/A	N/A
20	MA	N/A	ARU	ARU	DF	N/A	R	N/A	+3000	N/A	N/A	N/A	N/A	MAHF	N/A
30	MA	N/A	ARU	ARU	HM	137.21° Mag	R	N/A	+3000	N/A	N/A	1 MIN	N/A	MAHF	N/A

* Fictitious point = for coding purpose only.

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
ARU	S 10:58:54.93W 37:04:38.56
SIKAT	S 10:59:25.79W 36:54:29.12
PAKAD	S 10:59:10.41W 36:59:33.75
ARU03	S 10:58:58.07W 37:03:36.85

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT