



## CODING TABLE

IAC ILS V RWY 06					RIO BRANCO / Plácido de Castro (SBRB)							SBRB_IAC_00K		31 DEC 20	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	APCH	N/A	N/A	RB001	IF	N/A	N/A	N/A	+3000	N/A	N/A	N/A	N/A	IAF	RNAV 1 or RNP 1
20	APCH	N	N/A	RB004	TF	136.99° Mag 127.13° True	N/A	N/A	+3000	N/A	N/A	6.00	N/A	IF	RNAV 1 or RNP 1
10	APCH	N/A	N/A	RB003	IF	N/A	N/A	N/A	+3000	N/A	N/A	N/A	N/A	IAF	RNAV 1 or RNP 1
20	APCH	N	N/A	RB004	TF	357.09° Mag 347.18° True	N/A	N/A	+3000	N/A	N/A	6.00	N/A	IF	RNAV 1 or RNP 1
10	APCH	N/A	N/A	RB002	IF	N/A	N/A	N/A	+3000	N/A	N/A	N/A	N/A	IAF	RNAV 1 or RNP 1
20	APCH	N	N/A	RB004	TF	067.00° Mag / 057.16° True	N/A	N/A	+3000	N/A	N/A	6.00	N/A	IF	RNAV 1 or RNP 1
10	FINAL	N/A	N/A	RB004	IF	N/A	N/A	N/A	+3000	N/A	N/A	N/A	N/A	IF	N/A
20	FINAL	Y	IRB	RB006	CF	067.16° Mag / 057.11° True	N/A	N/A	R2280	N/A	N/A	4.99	N/A	FAF	N/A
30	FINAL	Y	IRB	RWY06	CF	067.17° Mag / 057.12° True	N/A	N/A	@686	N/A	N/A	5.00	-3.00	LTP	N/A
10	MA	Y	N/A	RB007	CF	067.18° Mag / 057.14° True	N/A	N/A	+3000	N/A	N/A	N/A	1.43	MAHF	RNAV 1 or RNP 1
20	MA	Y	N/A	RB007	HM	247.18° Mag / 237.00° True	R	N/A	+3000	N/A	N/A	1.00 min	N/A	MAHF	RNAV 1 or RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
IRB	S 09:51:40.20W 67:52:54.00
RB001	S 09:54:16.20W 68:07:29.40
RB002	S 10:01:10.80W 68:07:45.00
RB003	S 10:03:47.40W 68:01:17.40
RB004	S 09:57:54.60W 68:02:38.40
RB006	S 09:55:11.40W 67:58:23.40
RB007	S 09:46:22.20W 67:44:37.80

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT