



CODING TABLE

IAC RNP 327					CAMPOS DOS GOYTACAZES / Farol de São Tomé (SBFS)							SBFS_IAC_001		31 DEC 20	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST	VA (°)	Role of the Fix	Navigation Specification
10	APCH	N/A	N/A	FS003	IF	N/A	N/A	N/A	+2000	N/A	N/A	N/A	N/A	IAF	RNP APCH
20	APCH	N	N/A	FS002	TF	10.72° Mag / 347.01° True	N/A	N/A	+1300	N/A	N/A	3.00	N/A	IF	RNP APCH
10	APCH	N/A	N/A	FS004	IF	N/A	N/A	N/A	+2000	N/A	N/A	N/A	N/A	IAF	RNP APCH
20	APCH	N	N/A	FS002	TF	296.20° Mag / 272.48° True	N/A	N/A	+1300	N/A	N/A	3.01	N/A	IF	RNP APCH
10	FINAL	N/A	N/A	FS002	IF	N/A	N/A	N/A	+1300	N/A	N/A	N/A	N/A	IF	RNP APCH
20	FINAL	N	N/A	FS022	TF	329.23° Mag / 305.52° True	N/A	N/A	R1230	N/A	N/A	3.20	N/A	FAF	RNP APCH
30	FINAL	Y	N/A	FS023*	TF	327.26° Mag / 303.56° True	N/A	N/A	@45	N/A	N/A	3.00	-3.72	LTP/FTP	RNP APCH
10	MA	Y	N/A	FS007	TF	328.31° Mag / 304.62° True	N/A	N/A	+2000	N/A	N/A	6.22	+2.40	MAHF	RNP APCH
20	MA	Y	N/A	FS007	HM	328.33° Mag / 304.66° True	R	N/A	+2000	N/A	N/A	N/A	N/A	MAHF	RNP APCH

(*) Fictitious point only for coding purpose.

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
FS003	S 22:08:18.21W 40:57:52.72
FS002	S 22:05:22.20W 40:58:36.27
FS022	S 22:03:30.16W 41:01:24.64
FS004	S 22:05:30.08W 40:55:21.93
FS023	S 22:01:50.28W 41:04:06.08
FS007	S 21:58:17.31W 41:09:36.64

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT