

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
MSS	S 05:11:50.28W 37:21:52.01
FLZ	S 03:46:20.18W 38:32:51.68
AC018	S 04:17:14.61W 37:55:59.13
ISUGI	S 05:06:25.80W 38:30:54.60
GIBTO	S 04:42:59.20W 37:04:54.85

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT

DER	Latitude / Longitude (WGS84) DD:MM:SS.SS	Elevation (FT)
RWY09	S 04:33:58.31W 37:47:50.61	96