



## CODING TABLE

IAC RNAV(GNSS) A RWY 20					GUARATINGUETÁ / Guaratinguetá (SBGW)							SBGW_IAC_00L	31 DEC 20		
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST	VA (°)	Role of the Fix	Navigation Specification
10	APCH	N	N/A	OPTOD	IF	N/A	N/A	N/A	+7000	200	-	N/A	N/A	IAF	RNP APCH
20	APCH	N	N/A	GW018	TF	325.76° Mag 304.12° True	N/A	N/A	+4700	200	-	5.00	N/A	IF	RNP APCH
10	FINAL	N	N/A	GW018	IF	N/A	N/A	N/A	+4700	N/A	N/A	N/A	N/A	IF	RNP APCH
20	FINAL	N	N/A	GW019	TF	261.59° Mag 239.99° True	N/A	N/A	R3260	140	-	5.00	N/A	FAF	RNP APCH
30	FINAL	Y	N/A	GW021	TF	242.67° Mag 221.09° True	N/A	N/A	@2400	140	-	3.00	-3.00	MAPT	RNP APCH
10	MA	N	N/A	N/A	VA	242.67° Mag 221.09° True	N/A	N/A	+4000	180	-	N/A	2.86	N/A	RNP APCH
20	MA	N	N/A	OPTOD	DF	N/A	R	N/A	+7000	180	-	N/A	2.86	MAHF	RNP APCH
30	MA	N	N/A	OPTOD	HM	70.62° Mag 48.97° True	L	N/A	+7000	200	-	N/A	N/A	MAHF	RNP APCH

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
GW018	S 22:38:47.33W 45:04:06.55
GW019	S 22:41:17.98W 45:08:47.38
GW021	S 22:43:34.13W 45:10:55.30
OPTOD	S 22:41:36.41W 44:59:37.50

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT