

Identification	Aerodrome	<b>Chart Code</b>	AIRAC AMDT
STAR RNAV ISVAD 1A RWY 34	BELO HORIZONTE / Tancredo Neves, INTL (SBCF)	SBCF_STAR_01P	02 JAN 20

Seq	Transition	Path Terminator	Navaid / Fix / WPT	Type / Function	Flyover (Y/N)	Navaid	Course Mag (True)	Dist (NM)	Turn (L/R)	IAS (KT)	Altitude (FT)	Gradient (%)	Perform.
TRNS L	TRNS UTPIN												
010	Enroute	IF	UTPIN		N								
020	Enroute	TF	OPKES		N		026 (003.5T)	30.4					RNAV 1 (ou/or) RNP1
030	Enroute	TF	ISVAD		N		044 (021.9T)	25.1	R				RNAV 1 (ou/or) RNP1
TRNS C	TRNS OPKES												
010	Enroute	IF	OPKES		N								
020	Enroute	TF	ISVAD		N		044 (021.9T)	25.1					RNAV 1 (ou/or) RNP1
RWY 3	RWY 34												
010	Common	IF	ISVAD		N								
020	Common	TF	CF042		N		044 (021.9T)	26.1			+17000		RNAV 1 (ou/or) RNP1
030	Common	TF	CF048		N		075 (051.9T)	24.6	R		+11000		RNAV 1 (ou/or) RNP1
040	Common	TF	CF039		N		075 (052.2T)	6.0			+9000		RNAV 1 (ou/or) RNP1
050	Common	TF	KUGUT	IAF	N		161 (138.8T)	10.0	R	-210	+7000		RNAV 1 (ou/or) RNP1
060	Common	FM			N		130 ( )		L	-210	+7000		

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
ISVAD	S 20:17:57.00W 44:28:36.60
OPKES	S 20:41:20.02W 44:38:35.48
UTPIN	S 21:11:47.91W 44:40:33.35
CF042	S 19:53:36.65W 44:18:17.31
CF048	S 19:38:21.60W 43:57:49.20
CF039	S 19:34:39.75W 43:52:46.72
KUGUT	S 19:42:12.57W 43:45:47.39

COD	Meaning			
+	AT OR ABOVE			
-	AT OR BELOW			
=	MANDATORY			
	RECOMMENDED			
SDF	STEPDOWN FIX			
Υ	YES			
N	NO			
L	LEFT			
R	RIGHT			