

INSTRUMENT APPROACH
CHART (IAC)

ARAÇATUBA / Araçatuba (SBAU)

RNP RWY 05

AD ELEV: 1362'



ATIS NIL	APP NIL	AFIS ARAÇATUBA 130.60	GND C NIL
TEMP LNAV/VNAV MIN 0°C / MAX 50°C	FINAL CRS 049°	FAF: 3010'	LNAV/VNAV DA / (OCH): 1612' / (250')
		LNAV MDA / (OCH): 1750' / (390')	

APCH Perdida: Subir para **5000'**. Manter rumo **049** até **2000'**. Após, curvar a ESQUERDA direto para AU003 para espera.

Missed APCH: Climb to **5000'**. Maintain course **049** until **2000'**. After, turn LEFT direct to AU003 for holding.

RMK: NIL.

DEPARTAMENTO DE CONTROLE DO ESPAÇO AÉREO



AU001	4.0	3.0	2.0	1.1	0.6	RWY05	Ground Speed (KT)	90	110	130	150	170	190
3010	2686	2367	2049	1750	1612	ALT	FPM	500	600	700	800	900	NA
1648	1324	1005	687	390	250	(HGT)	FAF-MAPT	NA					

STRAIGHT-IN	CAT	A	B	C	D	E
	DA / (OCH)	1612' / (250')				NA
LNAV/VNAV	ALS/NO ALS/ RVR ALS (m)	NIL / 1300 / NIL				
	MDA / (OCH)	1750' / (390')				
LNAV	ALS/NO ALS/ RVR ALS (m)	NIL / 1600 / NIL		NIL / 1800 / NIL		
	MDA / (OCH)	NA				
CIRCLING	MDA / (OCH)	NA				
	VIS (m)	NA				

CHANGES: LAYOUT, IDENT, MNM OPR, PROC, TAA, DEC/VAR, IDENT.